# Product Data Sheet

## LANMASTER MPO optical adapter with flanges, black



**Part Number:** LAN-MPO-AM-MM

LANMASTER MPO optical adapter with flanges, black LAN-MPO-xM-MM: specifications, description, purpose and use in structured cabling, data center and LANMASTER infrastructure projects.

## Description

Adapters are pass-through sockets and are used for precise centering of connector tips and for fixing connectors pressed against each other.

Pass-through adapters provide connection of two MPO connectors, allow interconnecting MPO-MPO cable trunks or break-out cable assembles.

Fixing adapters in the front panel of a patch panel  is made by snap-on latches, you can use special screws to fix the adapters for additional reliability. Includes plastic caps to protect connectors from dust and dirt.

## Part Numbers

| | |
|---|---|
| LAN-MPO-AM-MM | LANMASTER MPO optical adapter with flanges, black |
| LAN-MPO-BM-MM | LANMASTER MPO optical adapter with flanges, black, type B (Key-up/Key-up) |
| LAN-MPO-BM-OM4 | LANMASTER MPO OM4, type B (Key-up/Key-up) |

Specifications are subject to change without notice. For the most current information, consult LANMASTER or an authorized LANMASTER partner/distributor.